# **Lab 1:**

# Task1: Configuring a DHCP Server

# Step-by-Step Guide

- 1. Set Up the Network Layout:
  - Place Devices: Open Cisco Packet Tracer, then add a Router, a Switch, and three PCs from the Network Devices and End Devices menus.
  - Connect Devices: Use the Connections (lightning icon) and select Automatic Connections to connect each PC to the Switch and the Switch to the Router.
- 2. Configure the Router as a DHCP Server:
  - Open the Router's GUI:
    - Click on the Router.
    - Select the **Config** tab.
  - o Enable DHCP on the Router:
    - Under Config > Global Settings, enable DHCP.

If GUI is not shown then write this command

#### Scenario:

- Network Address: 192.168.1.0/24
- Router Gateway (Default Router): 192.168.1.1
- **DNS Server**: 8.8.8.8 (Google DNS)
- DHCP Pool Name: LAN POOL
- Excluded IP Range: 192.168.1.1 192.168.1.10 (Reserved IPs)

# **Step-by-Step Commands**

1. Access the CLI on the router and enter privileged EXEC mode:

enable

2. Enter global configuration mode:

configure terminal

3. **Exclude the IP range** you don't want to be assigned by DHCP:

ip dhcp excluded-address 192.168.1.1 192.168.1.10

4. Create a DHCP pool with a name (e.g., LAN POOL):

ip dhcp pool LAN POOL

5. **Define the network and subnet mask** for the DHCP pool:

```
network 192.168.1.0 255.255.255.0
```

6. Set the default gateway (router) that clients should use:

```
default-router 192.168.1.1
```

7. Specify the DNS server IP address:

```
dns-server 8.8.8.8
```

8. Exit configuration mode:

end

9. Save the configuration (optional but recommended):

```
write memory
```

# **Complete Command Sequence**

Here's how the complete command sequence will look in the router CLI:

```
enable
configure terminal
ip dhcp excluded-address 192.168.1.1 192.168.1.10
ip dhcp pool LAN_POOL
network 192.168.1.0 255.255.255.0
default-router 192.168.1.1
dns-server 8.8.8.8
end
write memory
```

After these commands, your router will serve as a DHCP server for the network 192.168.1.0/24, assigning IP addresses starting from 192.168.1.11 up to 192.168.1.254 and providing the specified gateway and DNS information.

- 3. Set PCs to DHCP Mode:
  - Click each **PC** > **Desktop** > **IP Configuration**.
  - Select **DHCP** for IP Configuration. The PC should receive an IP address automatically from the DHCP server.
  - Verify each PC's IP address by going to **Desktop** > **Command Prompt**, typing ipconfig, and checking the assigned IP.
- 4. Testing DHCP:
  - o Check that each PC receives a unique IP address from the DHCP server.

## **Exercise Questions:**

- 1. What is DHCP, and how does it work in a network?
- 2. How does a device know it has successfully obtained an IP address from a DHCP serv

To place a server on the workspace in Cisco Packet Tracer, here is a detailed step-by-step guide from Lab 2 onward, breaking down each action clearly:

# Task 2: Setting Up an FTP Server

## **Step 1: Adding a Server to the Workspace**

- 1. **Open Cisco Packet Tracer**: Make sure you have Cisco Packet Tracer running.
- 2. Access Network Devices:
  - At the bottom of the screen, you'll see a row with icons labeled Network Devices and End Devices.
  - Click on Network Devices to view a set of options like Routers, Switches, and Servers.

#### 3. Select the Server Device:

- o In the **Network Devices** section, look for an icon labeled **Server**.
- Click on it to activate the server tool, which allows you to place servers on the workspace.

## 4. Place the Server:

- After clicking on the server icon, click anywhere on the empty workspace area to place the server.
- o A server icon should now appear on your workspace.

#### **Step 2: Connecting the Server to the Network**

#### 1. Connect the Server to the Switch:

- Use the **Connections** tool (the lightning icon) at the bottom of the screen to draw connections.
- Choose Automatic Connections, then click on the server and connect it to the Switch on the workspace.

#### 2. Configure the Server's IP Address:

- Click on the server to open its configuration window.
- o Go to the **Config** tab on the server window.
- o In the **FastEthernet0** section, assign a static IP address, such as 192.168.10.50.
- o Set the Subnet Mask to 255.255.255.0.

## **Step 3: Enable FTP Service on the Server**

### 1. Open the Services Tab:

- While still in the server configuration window, click on the **Services** tab.
- o From the list of services on the left, select **FTP**.

#### 2. Turn On FTP:

o By default, FTP might be off. Turn it **On** by clicking the power button.

## 3. Create an FTP User Account:

- o In the FTP section, add a Username and Password (for example, user1 and pass123).
- This will allow any connected PC to access the server's FTP service using these login credentials.

## Step 4: Access the FTP Server from a Client PC

## 1. Open a PC's Command Prompt:

- o Click on any **PC** connected to the switch to open its configuration window.
- o Go to **Desktop** > **Command Prompt**.

#### 2. Test the FTP Connection:

- o In the command prompt, type ftp 192.168.10.50 and press Enter.
- When prompted, enter the **Username** and **Password** you set up in the FTP service.
- o If successful, you'll be able to run FTP commands like put to upload files and get to download files.

# Task 3: Setting Up a Web Server

Follow similar steps for adding a server to the workspace and configuring it:

## Step 1: Adding and Configuring a Web Server

### 1. Place Another Server:

• Repeat the steps above to place another server on the workspace.

## 2. Assign an IP Address:

o Click on this new server, go to **Config**, and set a static IP address, such as 192.168.10.60.

### **Step 2: Enable HTTP Service**

#### 1. Go to Services Tab:

o In the **Services** tab, select **HTTP**.

#### 2. Turn on the HTTP Service:

- o Enable the HTTP service to make this server a web server.
- You can also customize the webpage content here, but the default settings will work fine

# Step 3: Access the Web Server from a Client PC

- 1. Open a PC's Web Browser:
  - o Go to **Desktop** > **Web Browser** on any PC.
- 2. Enter the Server's IP Address:
  - o In the URL bar, type http://192.168.10.60 and press Enter.
  - o This should load the default webpage hosted on the web server.

# **Task 4: Configuring DNS with an HTTP Server (Revised)**

## **Step-by-Step Guide**

## Step 1: Add and Configure the DNS Server

- 1. Place a Server on the Workspace:
  - Open Network Devices > End Devices at the bottom panel in Cisco Packet Tracer.
  - Select **Server** and place it on the workspace.
  - Connect the server to the Switch using the Connections tool (lightning icon).
     Choose Automatic Connections to create a link.
- 2. Assign an IP Address:
  - o Click on the server to open the **Physical Device** view.
  - o Go to the **Config** tab.
  - Under FastEthernet0, assign a static IP address, such as 192.168.10.60, and set the Subnet Mask to 255.255.255.0.

## **Step 2: Enable and Configure the DNS Service**

- 1. Access the Services Tab:
  - While still in the server's configuration window, go to the **Services** tab at the top.
- 2. Enable DNS:
  - In the left-hand column of services, select **DNS**.
  - You should see an option to turn **DNS Service On**—click to enable it.
- 3. Add a DNS Entry:
  - o You'll see a table to add domain names and their corresponding IP addresses.
  - o In the Name field, type mysite.com (or any domain name you'd like).
  - In the **Address** field, enter the IP address of the server running the HTTP service (192.168.10.60).
  - Click Add to save this DNS entry.

(At this point, your DNS table should show mysite.com with IP 192.168.10.60. This indicates that the DNS server will resolve mysite.com to the server's IP address.)

# **Step 3: Configure DNS Settings on Client PCs**

- 1. Set the DNS Server on Each Client PC:
  - o Click on each **PC** connected to the network to open its configuration.
  - Go to **Desktop** > **IP Configuration**.
  - o Under **DNS Server**, type 192.168.10.60 (the IP address of your DNS server).
  - o This tells each PC to use this server for resolving domain names.

## **Step 4: Testing the DNS and HTTP Configuration**

- 1. Open a Web Browser on a Client PC:
  - o On one of the PCs, go to **Desktop** > **Web Browser**.
- 2. Access the Website by Domain Name:
  - o In the URL bar, type http://mysite.com and press Enter.
  - o The browser should load the default webpage from the HTTP server. If it loads, it confirms that the DNS is resolving mysite.com to the HTTP server's IP address.

## **Exercise Questions:**

- 1. Why is DNS important in networking?
- 2. What would happen if the DNS server was unavailable?
- 3. How does DNS make it easier for users to access services over the network?